


- I** QUADRO COMANDO
- GB** CONTROL PANEL
- F** CENTRALE DE COMMANDE
- D** STEUERUNG
- E** CUADRO DE MANDOS
- P** QUADRO DE COMANDO



LEO MV D




ISTRUZIONI D'USO E DI INSTALLAZIONE
INSTALLATION AND USER'S MANUAL
INSTRUCTIONS D'UTILISATION ET D'INSTALLATION
INSTALLATIONS-UND GEBRAUCHSANLEITUNG
INSTRUCCIONES DE USO Y DE INSTALACION
INSTRUÇÕES DE USO E DE INSTALAÇÃO



AZIENDA CON SISTEMA DI GESTIONE
INTEGRATO CERTIFICATO DA DNV
= UNI EN ISO 9001:2000 =
UNI EN ISO 14001:2004

Via Lago di Vico, 44
 36015 Schio (VI)
 Tel.naz. 0445 696511
 Tel.int. +39 0445 696533
 Fax 0445 696522
 Internet: www.bft.it
 E-mail: sales@bft.it



Nel ringraziarVi per la preferenza accordata a questo prodotto, la ditta è certa che da esso otterrete le prestazioni necessarie al Vostro uso.

Leggete attentamente l'opuscolo "Libretto istruzioni" che lo accompagna in quanto esso fornisce importanti indicazioni riguardanti la sicurezza, l'installazione, l'uso e la manutenzione. Questo prodotto risponde alle norme riconosciute della tecnica e delle disposizioni relative alla sicurezza. Confermiamo che esso è conforme alle seguenti direttive europee: 89/336/CEE, 73/23/CEE, 98/37/CEE e loro modifiche successive.

1) GENERALITÀ

Il quadro comandi **LEO MV D** viene fornito dal costruttore con settaggio standard. Qualsiasi variazione, deve essere impostata mediante il programmatore a display incorporato o mediante **programmatore palmare universale**. La Centralina supporta completamente il protocollo EELINK compresa l'autoalimentazione del programmatore da centralina.

È disponibile in due versioni: per installazione esterna, all'interno della scatola SD, o montata e precablata all'interno dell'attuatore.

Le caratteristiche principali sono:

- Rallentamento della velocità all'accostamento.
- Regolazione elettronica della coppia.
- Frenatura elettrodinamica regolabile.
- Ingressi di fine-corsa chiusura / apertura
- Ingressi separati per le sicurezze.
- Ingresso orologio.
- Ingresso collegamento protocollo seriale (opzionale).
- Ricevitore radio incorporato

2) FUNZIONI

PER L'INSTALLATORE: compilare la tabella con i parametri impostati al fine di facilitare future modifiche e manutenzioni.

Tra parentesi quadre [] sono indicati i valori preimpostati.

MENU PARAMETRI

| | | | |
|---------------------------|-------|----------------------|---------------------------------|
| Tempo Chiusura Automatica | [10s] | <input type="text"/> | |
| Spazio rallentamento | [5] | <input type="text"/> | Impostabile solo con BARRIERA=1 |
| Tempo allarme | [30s] | <input type="text"/> | |
| Zona | [0] | <input type="text"/> | |
| Coppia rallentamento | [99%] | <input type="text"/> | Impostabile solo con BARRIERA=1 |
| Coppia apertura | [70%] | <input type="text"/> | Impostabile solo con BARRIERA=1 |
| Coppia chiusura | [70%] | <input type="text"/> | Impostabile solo con BARRIERA=1 |
| Freno | [52%] | <input type="text"/> | |
| Encoder | [1] | <input type="text"/> | Impostabile solo con BARRIERA=0 |
| Tipo di barriera | [1] | <input type="text"/> | |

MENU Logiche

| | | |
|-----------------------------|-------|----------------------|
| TCA | [ON] | <input type="text"/> |
| 3 Passi | [ON] | <input type="text"/> |
| Blocca Impulsi apertura | [ON] | <input type="text"/> |
| Blocca Impulsi TCA | [OFF] | <input type="text"/> |
| Pre allarme | [OFF] | <input type="text"/> |
| Fotocellule in apertura | [ON] | <input type="text"/> |
| Chiusura rapida | [OFF] | <input type="text"/> |
| Allarme SCA | [ON] | <input type="text"/> |
| Master/Slave | [OFF] | <input type="text"/> |
| Test fotocellule (PHOT) | [OFF] | <input type="text"/> |
| Test costa sensibile (BAR) | [OFF] | <input type="text"/> |
| Codice fisso | [OFF] | <input type="text"/> |
| Programmazione radiocomandi | [ON] | <input type="text"/> |

3) DEMOLIZIONE

Attenzione: Avvalersi esclusivamente di personale qualificato.

L'eliminazione dei materiali va fatta rispettando le norme vigenti. Nel caso di demolizione, non esistono particolari pericoli o rischi derivanti dal prodotto stesso. È opportuno, in caso di recupero dei materiali, che vengano separati per tipologia (parti elettriche - rame - alluminio - plastica - ecc.).

4) SMANTELLAMENTO

Attenzione: Avvalersi esclusivamente di personale qualificato.

Nel caso la centralina venga smontata per essere poi rimontata in altro sito bisogna:

- Togliere l'alimentazione e scollegare tutto l'impianto elettrico.
- Nel caso alcuni componenti non possano essere rimossi o risultino danneggiati, provvedere alla loro sostituzione.

AVVERTENZE

Il buon funzionamento dell'operatore è garantito solo se vengono rispettati i dati riportati in questo manuale. La ditta non risponde dei danni causati dall'inosservanza delle norme di installazione e delle indicazioni riportate in questo manuale.

Le descrizioni e le illustrazioni del presente manuale non sono impegnative. Lasciando inalterate le caratteristiche essenziali del prodotto, la Ditta si riserva di apportare in qualunque momento le modifiche che essa ritiene convenienti per migliorare tecnicamente, costruttivamente e commercialmente il prodotto, senza impegnarsi ad aggiornare la presente pubblicazione.

USER'S MANUAL

ENGLISH

Thank you for buying this product, our company is sure that you will be more than satisfied with the product's performance. The product is supplied with a "Warnings" leaflet and an "Instruction booklet". These should both be read carefully as they provide important information about safety, installation, operation and maintenance. This product complies with the recognised technical standards and safety regulations. We declare that this product is in conformity with the following European Directives: 89/336/EEC and 73/23/EEC, 98/37/EEC (and subsequent amendments).

1) GENERAL OUTLINE

The **LEO MV D** control panel is supplied by the manufacturer with standard setting. Any alteration must be set by means of the incorporated display programmer or by means of **universal palmtop programmer**. The Control unit completely supports the EELINK protocol, including the programmer self-supply from the control unit. It is available in two versions: one for external installation, inside the SD box, the other fitted and pre-wired inside the controller.

Its main characteristics are:

- Slow down of end-of-run speed.
- Electronic torque setting
- Adjustable electrodynamic braking
- Closing / opening limit-switch inputs
- Separate inputs for safety devices
- Clock input
- Serial protocol connection input (Option).
- Incorporated radio receiver

2) FUNCTIONS

FOR THE INSTALLER: Fill in the table with the parameters set, in order to facilitate future modifications and maintenance operations.

The preset values are indicated between square brackets [].

PARAMETER MENU

| | | | |
|------------------------------|-------|----------------------|-----------------------------------|
| Automatic Closing Time (TCA) | [10s] | <input type="text"/> | |
| Slow-down Distance | [5] | <input type="text"/> | Can be set with "Barrier"=1 only. |
| Alarm time | [30s] | <input type="text"/> | |
| Zona | [0] | <input type="text"/> | |
| Slow-down torque | [99%] | <input type="text"/> | Can be set with "Barrier"=1 only. |
| Opening torque | [70%] | <input type="text"/> | Can be set with "Barrier"=1 only. |
| Closing torque | [70%] | <input type="text"/> | Can be set with "Barrier"=1 only. |
| Brake | [52%] | <input type="text"/> | |
| Encoder | [1] | <input type="text"/> | Can be set with "Barrier"=0 only. |
| Type of barrier | [1] | <input type="text"/> | |

Logic MENU

| | | |
|-------------------------------|-------|----------------------|
| TCA | [ON] | <input type="text"/> |
| 3 Steps | [ON] | <input type="text"/> |
| Impulse locking | [ON] | <input type="text"/> |
| TCA impulse locking | [OFF] | <input type="text"/> |
| Pre-alarm | [OFF] | <input type="text"/> |
| Photocells on opening | [ON] | <input type="text"/> |
| Rapid closing | [OFF] | <input type="text"/> |
| SCA alarm | [ON] | <input type="text"/> |
| Master/slave | [OFF] | <input type="text"/> |
| Photocell test | [OFF] | <input type="text"/> |
| Electric edge test | [OFF] | <input type="text"/> |
| Fixed code | [OFF] | <input type="text"/> |
| Radio transmitter programming | [ON] | <input type="text"/> |

3) SCRAPPING

Warning: This operation should only be carried out by qualified personnel. Materials must be disposed of in conformity with the current regulations. In case of scrapping, the automation devices do not entail any particular risks or danger. In case of materials to be recycled, these should be sorted out by type (electrical components, copper, aluminium, plastic etc.).

4) DISMANTLING

Warning: This operation should only be carried out by qualified personnel.

When the control unit is disassembled to be reassembled on another site, proceed as follows:

- Disconnect the power supply and the entire electrical installation.
- In the case where some of the components cannot be removed or are damaged, they must be replaced.

WARNINGS

Correct controller operation is only ensured when the data contained in the present manual are observed. The company is not to be held responsible for any damage resulting from failure to observe the installation standards and the instructions contained in the present manual.

The descriptions and illustrations contained in the present manual are not binding. The Company reserves the right to make any alterations deemed appropriate for the technical, manufacturing and commercial improvement of the product, while leaving the essential product features unchanged, at any time and without undertaking to update the present publication.

Thank you for buying this product, our company is sure that you will be more than satisfied with the product's performance. The product is supplied with a "Warnings" leaflet and an "Instruction booklet". These should both be read carefully as they provide important information about safety, installation, operation and maintenance. This product complies with the recognised technical standards and safety regulations. We declare that this product is in conformity with the following European Directives: 89/336/EEC and 73/23/EEC, 98/37/EEC (and subsequent amendments).

1) GENERAL SAFETY

WARNING! An incorrect installation or improper use of the product can cause damage to persons, animals or things.

- The "Warnings" leaflet and "Instruction booklet" supplied with this product should be read carefully as they provide important information about safety, installation, use and maintenance.
- Scrap packing materials (plastic, cardboard, polystyrene etc) according to the provisions set out by current standards. Keep nylon or polystyrene bags out of children's reach.
- Keep the instructions together with the technical brochure for future reference.
- This product was exclusively designed and manufactured for the use specified in the present documentation. Any other use not specified in this documentation could damage the product and be dangerous.
- The Company declines all responsibility for any consequences resulting from improper use of the product, or use which is different from that expected and specified in the present documentation.
- Do not install the product in explosive atmosphere.
- The construction components of this product must comply with the following European Directives: 89/336/CEE, 73/23/EEC, 98/37/EEC and subsequent amendments. As for all non-EEC countries, the above-mentioned standards as well as the current national standards should be respected in order to achieve a good safety level.
- The Company declines all responsibility for any consequences resulting from failure to observe Good Technical Practice when constructing closing structures (door, gates etc.), as well as from any deformation which might occur during use.
- The installation must comply with the provisions set out by the following European Directives: 89/336/CEE, 73/23/EEC, 98/37/EEC and subsequent amendments.
- Disconnect the electrical power supply before carrying out any work on the installation. Also disconnect any buffer batteries, if fitted.
- Fit an omnipolar or magnetothermal switch on the mains power supply, having a contact opening distance equal to or greater than 3,5 mm.
- Check that a differential switch with a 0.03A threshold is fitted just before the power supply mains.
- Check that earthing is carried out correctly: connect all metal parts for closure (doors, gates etc.) and all system components provided with an earth terminal.
- Fit all the safety devices (photocells, electric edges etc.) which are needed to protect the area from any danger caused by squashing, conveying and shearing.
- Position at least one luminous signal indication device (blinker) where it can be easily seen, and fix a Warning sign to the structure.
- The Company declines all responsibility with respect to the automation safety and correct operation when other manufacturers' components are used.
- Only use original parts for any maintenance or repair operation.
- Do not modify the automation components, unless explicitly authorised by the company.
- Instruct the product user about the control systems provided and the manual opening operation in case of emergency.
- Do not allow persons or children to remain in the automation operation area.
- Keep radio control or other control devices out of children's reach, in order to avoid unintentional automation activation.
- The user must avoid any attempt to carry out work or repair on the automation system, and always request the assistance of qualified personnel.
- Anything which is not expressly provided for in the present instructions, is not allowed.
- Installation must be carried out using the safety devices and controls prescribed by the EN 12978 Standard.

2) GENERAL OUTLINE

The **LEO MV D** control panel is supplied by the manufacturer with standard setting. Any alteration must be set by means of the incorporated display programmer or by means of universal palmtop programmer. The Control unit completely supports the EELINK protocol.

It is available in two versions: one for external installation, inside the SD box, the other fitted and pre-wired inside the controller.

Its main characteristics are:

- Slow down of end-of-run speed.
- Electronic torque setting
- Adjustable electrodynamic braking
- Closing / opening limit-switch inputs
- Separate inputs for safety devices
- Clock input
- Serial protocol connection input (optional)
- Incorporated radio receiver

The board is provided with a terminal board which can be pulled out for easier maintenance or replacement. The board is supplied with a series of pre-wired jumpers to facilitate the installer's work.

The jumpers relate to the following terminals: 21-23, 21-24 and 21-30. If the above-mentioned terminals are in use, remove their respective jumpers.

3) TECHNICAL SPECIFICATIONS

Power supply: 230V±10% 50Hz*
 Mains/low voltage insulation: > 2MΩ 500V~
 Dielectric strength: mains/low voltage 3750V~ for 1 minute
 Motor output current: 1.5A max
 Maximum motor power: 750W
 Supply to accessories: 24V~ (1A max absorption)
 Gate-open warning light: 24V~ 3W max
 Blinker: 230V 40W max
 Dimensions: see figure 1
 Fuses: see figure 2
 (* other voltages available on request)


4) TERMINAL BOARD CONNECTIONS (Fig.3)

WARNING – During the wiring and installation operations, refer to the current standards as well as principles of good technical practice.

The cables must be tied by additional fastening next to the terminals, by means of clips for example.

All the operator wiring operations must be carried out by qualified personnel.

JP1

1  GND terminal
 2-3 Single-phase mains supply 230V±10% 50Hz (2=N) (3=L)

JP2

4-5 Blinker connection (mains voltage) 40W Max.
 6-7-8-9 Motor connection:
 6 operation 1 + capacitor
 7 common (blue)
 8 operation 2
 9 capacitor

JP3

10-11 Output 24V~ 1A max – power supply for photocells or other devices.
 12-13 Gate-open warning light output (24V 3W max)

JP4

Barrier status output
 20-18 Closed Contact with barrier raised
 20-19 Closed Contact with barrier lowered
 Contact switching for barrier status control.
 To be used in Parky systems (see paragraph 13)

JP5

Encoder connection
WARNING! The maximum length of the connection cable of the encoder should not exceed 3.00 mt.

JP8

21-22 Open-Close button (N.O. Start), key selector.
 21-23 Block button (N.C. Stop). If not used, leave jumped.
 21-24 Photocell input (N.C.). If not used, leave jumped.
 21-25 Opening limit switch connection (N.C. SWO). If not used, leave jumped.
 21-26 Closing limit switch connection (N.C. SWC). If not used, leave jumped.
 21-27 Not used
 21-28 Open-Button connection (N.O. Open)
 21-29 Close-Button connection (N.O. Close)
 21-30 Rubber edge connection (N.C.). If not used, leave jumped.
 21-31 **Connection of clock input (N.O.).** If the contact connected is open, the barrier closes and gets ready for normal operation. If the contact is closed (N.C.), the barrier opens and remains open until contact opening.

JP9

32 Photocell check input (PHOT FAULT) (see Fig. 3)
 33 Electric edge check input (EDGE FAULT) (see Fig. 3)
 38-39 Antenna input for radio-receiver (38 signal - 39 braid). Cable RG58.

5) PROGRAMMING

The control panel provided with a microprocessor is supplied with function parameters preset by the manufacturer, suitable for standard installations. The predefined parameters can be altered by means of either the incorporated display programmer or universal palmtop programmer.

In the case where programming is carried out by means of universal palmtop programmer, carefully read the instructions relating to universal palmtop programmer, and proceed in the following way.

Connect the universal palmtop programmer to the control unit through the UNIFLAT accessory (See fig. 4). Enter the "CONTROL UNITS" menu, and the "PARAMETERS" submenu, then scroll the display screenfuls using the up/down arrows, and set the numerical values of the parameters listed below.

For the function logics, refer to the "LOGIC" submenu.

In the case where programming is carried out by means of the incorporated programmer, refer to Fig. A and B and to the "configuration" paragraph.

6) CONFIGURATION

The display programmer is used to set all the LEO MV D control panel functions.

The programmer is provided with three pushbuttons for menu scrolling and function parameter configurations:

- + menu scrolling/value increment key
- menu scrolling/value reduction key

OK Enter (confirm) key

The simultaneous pressure of the + and - keys is used to exit the active menu and move to the preceding menu.

If the + and - keys are pressed simultaneously at the main menu level (parameters, logics, radio, language, autosetting), programming is exited and the display is switched off (the OK message is displayed).

The modifications made are only set if the OK key is subsequently pressed.

When the OK key is pressed for the first time, the programming mode is entered.

The following pieces of information appear on the display at first:

- Control unit Software version
- Number of total manoeuvres carried out (the value is expressed in thousands, therefore the display constantly shows 0000 during the first thousand manoeuvres)
- Number of manoeuvres carried out since the latest maintenance operation (the value is expressed in thousands, therefore the display constantly shows 0000 during the first thousand manoeuvres)
- Number of memorised radio control devices.

When the OK key is pressed during the initial presentation phase, the first menu (parameters) can be accessed directly.

Here follows a list of the main menus and the respective submenus available.

The predefined parameter is shown between square brackets [0].

The writing appearing on the display is indicated between round brackets. Refer to Figures A and B for the control unit configuration procedure.

6.1) Parameter Menu (PRRrP)

1 - Automatic Closing Time (tcr) [10s]

Set the numerical value of the automatic closing time from 1 to 180 seconds.

2 - Slow-down Distance (crl, rrl) [5]

Set the required slow-down distance for opening and closing between 1 and 90.

NOTE: power failure, reset, or manual gate release, the control panel carries out a complete manoeuvre at reduced speed, in order to learn the length of stroke.

3- Alarm time (RLRrP, t iPE) [30s]

In the case of obstacle detection or photocell engagement, at the end of the time set (ranging from 10s to 240s) the SCA contact is closed. The contact is subsequently opened by the STOP command or by triggering of the closing limit switch. Only active when the SCA Alarm logic is set to OFF.

4- Zone (zonE) [0]

Set the zone number between a minimum value of 0 and a maximum value of 128. See paragraph 8 on "Serial connection".

5- Slow-down torque (SLUd tarQUE) [99%]

Set the motor torque value during the slow-down phase between 0% and 99%.

6- Opening torque (oPEn tarQUE) [70%]

Set the motor opening torque value between 1% and 99%.

7- Closing torque (cL5. tarQUE) [70%]

Set the motor closing torque value between 1% and 99%.

8 - Brake (brAKE) [52%]

Set the required brake value between 0 and 99%, compatibly with the weight of the rod and the existing stresses.

9 - Encoder (EncodEr) [1]

0: encoder disabled: timed slow-down, obstacle detection function not active. (The encoder can be disconnected).

1: encoder enabled: slow-down and obstacle detection by means of encoder (default).

⚠ WARNING: Check that the impact force value measured at the points established by the EN 12445 standard is lower than that specified in the EN 12453 standard.

⚠ Incorrect sensitivity setting can cause injuries to persons or animals, or damage to things.

10- Type of barrier (bRr r iEr) [1]

0: MOOVI 30RMM/50RMM mod. barrier

1: MOOVI 30S mod. barrier

2: BGV mod. barrier

Factory-preset value, in case of maintenance or malfunctions, check the correspondence between the setting and the barrier model.

With the MOOVI 30RMM/50RMM barrier (0) , the following functions are not active:

- slow down
- torque setting (the barrier always works at maximum torque).

With the BGV barrier (2) , the following functions are not active:

- slow down
- torque setting (the barrier always works at maximum torque).
- obstacle detection.

6.2) Logic Menu (LoG ic)

- TCA (tcr) [ON]

ON: Activates automatic closing

OFF: Excludes automatic closing

- 3 Steps (3 StEP) [ON]

ON: Enables 3-step logic. A start impulse has the following effects:

barrier closed:.....opens
 on opening:stops and enters TCA (if configured)
 barrier open:..... closes
 on closing: stops and reverses movement
 after stopping:.....opens

OFF: Disables 3-step logic

- Opening Impulse lock (iBl oPEn) [ON]

ON: The Start impulse has no effect during the opening phase.

OFF: The Start impulse becomes effective during the opening phase.

- Impulse lock TCA (iBl tcr) [OFF]

ON: The Start impulse has no effect during the TCA dwell period.

OFF: The Start impulse becomes effective during the TCA dwell period.

- Pre alarm (PRE-RLRrP) [OFF]

ON: The blinker comes on about 3 seconds before the motor starts.

OFF: The blinker comes on at the same time as the motor starts.

- Photocells on opening (Photo. oPEn) [ON]

ON: In case of obscuring, this excludes photocell operation on opening. During the closing phase, it immediately reverses the motion.

OFF: In case of obscuring, the photocells are active both on opening and on closing. When a photocell is obscured on closing, it reverses the motion only after the photocell is disengaged.

- Rapid closing (FR5t cL5) [OFF]

ON: Closes barrier after photocell disengagement, before waiting for the end of the TCA (automatic closing time) set.

OFF: Command not entered.

- SCA Alarm (ScR RL RrP) [ON]

ON: The SCA contact (terminals 12-13) behaves as follows:

with barrier open and on opening:..contact closed (warning light on)
 with barrier closed:contact open.....(warning light off)
 on closing: intermittent contact (blinking)

OFF: The SCA contact closes according to the modes set by the Alarm Time parameter.

- Master/Slave (rR5tEr) [OFF]

ON: The control panel is set as Master in a centralised connection (see Paragraph 7).

OFF: The control panel is set as Slave in a centralised connection (see Paragraph 7).

- Photocell test (tE5t Photo) [OFF]

ON: Activates photocell check (see Fig. 3)

OFF: Deactivates photocell check

- Electric edge test (tE5t bRr) [OFF]

ON: Activates electric edge check (see Fig. 3)

OFF: Deactivates electric edge check

- Fixed code (F iHEd codE) [OFF]

ON: The receiver is configured for operation in fixed-code mode, see paragraph on "Radio Transmitter Cloning".

OFF: The receiver is configured for operation in rolling-code mode, see paragraph on "Radio Transmitter Cloning".

- Radio transmitter programming (rRd io Prdū) [ON]

ON: This enables transmitter storage via radio:
 1 – First press the hidden key (P1) and then the normal key (T1, T2, T3 or T4) of a transmitter already memorised in standard mode by means of the radio menu.
 2 – Within 10s press the hidden key (P1) and the normal key (T1, T2, T3 or T4) of a transmitter to be memorised.
 The receiver exits the programming mode after 10s, other new transmitters can be entered before the end of this time.
 This mode does not require access to the control panel.
 OFF: This disables transmitter storage via radio.
 The transmitters can only be memorised using the appropriate Radio menu.

6.3) Radio Menu (rRd io)

- **Add start (Rdd StRr-t)**
 Associates the required key to Start command
- **Read (rERd)**
 Checks one key of a receiver; if stored it displays a message showing the receiver number in the memory location (from 01 to 64), and the key number (T1, T2, T3 or T4).
- **Eliminate list (ErERSE 54)**
WARNING! Completely removes all memorised radio control devices from the receiver memory.
- **Receiver code reading (rH codE)**
 This displays the code entered in the receiver.

6.4) Language Menu (LrncūRūE)

Allows you to set the language on the display programmer.
 5 languages are available:

- **ITALIAN (tR)**
- **FRENCH (FrR)**
- **GERMAN (dEū)**
- **ENGLISH (Erū)**
- **SPANISH (E5P)**

6.5) MENU DEFAULT (dEFrūLū)

Restores the preset default values on the control unit. After restoring, a new autose operation must be carried out.

6.6) DIAGNOSTICS AND MONITORING

The display on the **LEO MV D** panel shows some useful information, both during normal operation and in the case of malfunctions.

Diagnostics:

In the case of malfunctions, the display shows a message indicating which device needs to be checked:

- STRT = START input activation
- STOP = STOP input activation
- PHOT = PHOT input activation
- FLT = FAULT input activation for checked photocells
- SWO = input activation OPENING LIMIT SWITCH
- SWC = input activation CLOSING LIMIT SWITCH
- OPEN = OPEN input activation
- CLS = CLOSE input activation
- BAR = input activation SAFETY EDGE
- TIME = TIMER input activation

In the case where an obstacle is found, the **LEO MV D** panel stops the door and activates a reverse manoeuvre; at the same time the display shows the "BAR" message.

6.7) Statistics

Having connected the universal palmtop programmer to the control unit, enter the CONTROL UNIT / STATISTICS menu and scroll the screenful showing the statistical parameters:

- Board microprocessor software version.
- Number of cycles carried out. If motors are replaced, count the number of manoeuvres carried out up to that time.
- Number of cycles carried out from the latest maintenance operation. It is automatically set to zero after each self-diagnosis or parameter writing.
- Date of latest maintenance operation. To be updated manually from the appropriate menu "Update maintenance date".
- Installation description. 16 characters can be entered for installation identification.

7) CONNECTION TO PARKY CAR-PARK MANAGEMENT SYSTEM

The board is provided with an output (terminal JP4) for controlling the barrier status, configured as follows (Fig.7):

- contact **closed** between terminals **19 and 20** with barrier **lowered**
- contact **closed** between terminals **18 and 20** with barrier **raised**.

8) SERIAL CONNECTION USING SCS1 BOARD (Fig.5)

The **LEO-MV-D** control panel allows several automation units (SCS1) to be connected in a centralised way by means of appropriate serial inputs and outputs. This makes it possible to use one single command to open and close all the automation units connected.

Following the diagram in Fig.5, proceed to connecting all the **LEO-MV-D** control panels, exclusively using a telephone-type line.

Should a telephone cable with more than one pair be needed, it is indispensable to use wires from the same pair.

The length of the telephone cable between one appliance and the next must not exceed 250 m.

At this point, each of the **LEO-MV-D** control panels must be appropriately configured, by setting a MASTER unit first of all, which will have control over all the others, to be necessarily set as SLAVE (see logic menu).

Also set the Zone number (see parameter menu) between 0 and 127.

The zone number allows you to create groups of automation units, each one answering to the Zone Master unit. **Each zone can only be assigned one Master unit, the Master unit in zone 0 also controls the Slave units in the other zones.**

8.1) Opposite barriers/gates (Fig.6)

Only with 3.7 or later microprocessor version.

By means of a serial connection, it is also possible to obtain centralised control of two opposite barriers/gates.

In this case, the Master M1 control panel will simultaneously manage closing and opening for the Slave M2 control panel.

SETTING REQUIRED FOR OPERATION:

- MASTER board: ZonE=128, PR5tEr=ON
- SLAVE board: ZonE=128, PR5tEr=OFF

WIRING REQUIRED FOR OPERATION:

- The MASTER and SLAVE control units are interconnected through the 4 wires (RX/TX) for the SCS1 interface boards;
- All the activation controls, as well as the remote controls must refer to the MASTER board;
- All the photocells (checked or unchecked) must be connected to the MASTER control panel;
- The safety edges (checked or unchecked) of the MASTER leaf must be connected to the MASTER control unit;
- The safety edges (checked or unchecked) of the SLAVE leaf must be connected to the SLAVE control unit.

9) SCRAPPING

Materials must be disposed of in conformity with the current regulations. In case of scrapping, the automation devices do not entail any particular risks or danger. In case of recovered materials, these should be sorted out by type (electrical components, copper, aluminium, plastic etc.).

10) DISMANTLING

WARNING: before opening the door, make sure that the spring has been unloaded (rod at 43°). When the automation system is disassembled to be reassembled on another site, proceed as follows:

- Disconnect the power supply and the entire electrical installation.
- Remove the actuator from its fixing base.
- Disassemble all the installation components.
- In the case where some of the components cannot be removed or are damaged, they must be replaced.

WARNINGS

Correct controller operation is only ensured when the data contained in the present manual are observed. The company is not to be held responsible for any damage resulting from failure to observe the installation standards and the instructions contained in the present manual.

The descriptions and illustrations contained in the present manual are not binding. The Company reserves the right to make any alterations deemed appropriate for the technical, manufacturing and commercial improvement of the product, while leaving the essential product features unchanged, at any time and without undertaking to update the present publication.

Fig. A

D811512_03








Fig.B





Collegamento dispositivi di sicurezza verificati, Connection of tested safety devices, Connexion des dispositifs de sécurité vérifiés, Anschluß geprüfte Sicherheitsvorrichtungen, Conexión de los dispositivos de seguridad controlados, Ligaçõn de dispositivos de segurança controlados




Fig. 4






Fig. 5




Fig. 6









Fig. 7



BFT S.P.A.

Via Lago di Vico 44
36015 Schio (VI) / *Italy*
Tel. 0039 445.696511 - Fax 0039 445.696522
www.bft.it - e-mail: sales@bft.it

**BFT TORANTRIEBSSYSTEME GmbH**

Faber-Castell Str. 29
90522 Oberasbach / *Germany*
Tel. 0049 911 7660090 - Fax 0049 911 7660099
e-mail: service@bft-torantriebe.de

BFT AUTOMATION UK LTD

Unit 8E, Newby Road
Industrial Estate Hazel Grove
Stockport SK7 5DA / *England*
Tel. 0044 161 4560456 - Fax 0044 161 4569090
e-mail: info@bft.co.uk

AUTOMATISMES BFT FRANCE

13 Bdl. E. Michelet
69008 Lyon / *France*
Tel. 0033 4 78 76 09 88 - Fax 0033 4 78 76 92 23
e-mail: infofrance@bft.it

BFT BENELUX SA

Rue du commerce 12
1400 Nivelles / *Belgium*
Tel. 0032 67/ 55 02 00 - Fax 0032 67/ 55 02 01
mail: info@bftbenelux.be

BFT-ADRIA d.o.o.

Obrovac 39
51218 Dražice (RIJEKA) / *Croatia*
Tel. 00385 51 502 640 - Fax 00385 51 502 644
www.bft.hr - e-mail: info@bft.hr

BFT Polska Sp. z o.o.

ul. Szatwiowa 47
03-167 Warszawa / *Polska*
Tel. 0048 022 814 12 22 - Fax 0048 022 814 39 18
www.bft.com.pl - e-mail: biuro@bft.com.pl

BFT GROUP

ITALIBERICA DE AUTOMATISMOS S.L.
España
www.bftautomatismos.com

P.I. Palau Nord, Sector F
C/Cami Can Basa nº 6-8
08400 GRANOLLERS *Barcelona*
Telf. +34 93 8614828 - Fax +34 93 8700394
e-mail: bftbcn@bftautomatismos.com

P.I. Comendador,
C/ informática, Nave 22
19200 AZUQUECA DE HENARES *Guadalajara*
Telf. +34 949 26 32 00 - Fax. +34 949 26 24 51
e-mail: bft@bftautomatismos.com