




**ATTENZIONE 230V / ATTENTION 230V /
ATTENTION 230V / ACHTUNG 230V / ATENCIÓN 230V**

Prima di effettuare qualsiasi intervento sull'impianto togliere l'alimentazione elettrica mediante un sezionatore.
Always disconnect the electricity with a cut-off switch before attempting any work on the system.
Avant toute intervention sur l'installation, couper l'électricité à l'aide d'un sectionneur.
Vor allen Arbeiten an der Anlage ist die Spannungsversorgung durch einen Trennschalter zu unterbrechen.
Antes de efectuar cualquier intervención en la instalación, cortar la alimentación eléctrica mediante un seccionador.



Connessioni elettriche cappello luci / Electrical connections light cap

Connexions électriques couronne lumières / Stromanschluss lichtkappe / Conexiones eléctricas capuchón luces

P800104 - ALLU



Connettore controparte (non fornito)
Counterpart connector (not supplied)
Connecteur et contrepairtie (non fourni)
Gegensteckverbinder (nicht geliefert)
Conector contraparte (no incluido)



- **N° 1 AMP cod. 282088-1**
Connettore femmina / Female connector /
Connecteur femelle / Buchse /
Conector hembra

- **N° 4 AMP cod. 183035-1**
Contatti / Pins / Contacts / Kontakte /
Contactos

- **N° 4 AMP cod. 281934-2**
Guarnizioni cavi / Wire seals /
Garnitures câbles / Kabeldichtungen /
Juntas cables

**(!) Non collegare / Do not connect /
Ne pas brancher / Nicht anschließen / No conectar**

Bft Spa
Via Lago di Vico, 44 ITALY
36015 Schio (VI)
T +39 0445 69 65 11
F +39 0445 69 65 22
→www.bft-automation.com

SPAIN
BFT GROUP ITALIBERICA DE AUTOMATISMOS S.L.
08401 Granollers - (Barcelona)
www.bftautomatismos.com

FRANCE
AUTOMATISMES BFT FRANCE
69800 Saint Priest
www.bft-france.com

GERMANY
BFT TORANTRIEBSSYSTEME GmbH
90522 Oberasbach
www.bft-torantrieb.de

UNITED KINGDOM
BFT AUTOMATION UK LTD
Heaton Mersey, Stockport SK4 3GL
www.bft.co.uk

IRELAND
BFT AUTOMATION LTD
Dublin 12

BENELUX
BFT BENELUX SA
1400 Nivelles
www.bftbenelux.be

POLAND
BFT POLSKA SP. Z O.O.
05-091 ZĄBKÓW
www.bft.pl

CROATIA
BFT ADRIA D.O.O.
51218 Drazice (Rijeka)
www.bft.hr

PORTUGAL
BFT SA-COMERCIO DE AUTOMATISMOS E MATERIAL DE SEGURANCIA
3026-901 Coimbra
www.bftportugal.com

CZECH REPUBLIC
BFT CZ S.R.O.
Praha
www.bft.it

TURKEY
BFT OTOMATIK KAPI SISTEMELERI SANAY VE
Istanbul
www.bftotomasyon.com.tr

RUSSIA
BFT RUSSIA
111020 Moscow
www.bfttrus.ru

AUSTRALIA
BFT AUTOMATION AUSTRALIA PTY LTD
Wetherill Park (Sydney)
www.bftaustralia.com.au

U.S.A.
BFT USA
Boca Raton
www.bft-usa.com

CHINA
BFT CHINA
Shanghai 200072
www.bft-china.cn

UAE
BFT Middle East FZCO
Dubai

